

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

0-2 - NMOC-D-HOBBS 1-ENGR-JDM
1-FILE 1-FOREMAN-
1-LAURA RICHARDSON-MIDLAND
-WIO's BW-CHG OF WELL STATUS

Form C-103
Revised 10-1-7

54. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	LG 968

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - "A" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Getty Oil Company	8. Farm or Lease Name Sims 27 State
3. Address of Operator P.O. Box 730 Hobbs, NM 88240	9. Well No. 1
4. Location of Well UNIT LETTER <u>G</u> , <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>27</u> TOWNSHIP <u>20S</u> RANGE <u>35E</u> NMPM.	10. Field and Pool, or Wildcat Osudo Morrow
15. Elevation (Show whether DF, RT, GR, etc.) 2678.1 GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- TOH with tubing and packer.
- Set 7" CIBP @ 8850' and dump 35' cement on top.
- TIH with tubing open ended to + 5300' and spot 100' class C cement plug.
- Raise up to top of Rustler @ 1976' and spot 100' class C cement plug.
- Raise up to last joint and spot 25' class C cement at surface. Cut off wellhead and install dry hole marker.

Verbal approval obtained from Jerry Sexton by Howard Smith.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John R. Crockett TITLE Area Superintendent DATE 8/4/82

ORIGINAL SIGNED BY
JERRY SEXTON

APPROVED BY JERRY SEXTON TITLE DISTRICT 1 SUPR. DATE AUG 6 1982

CONDITIONS OF ADJUDICATION, IF ANY: