

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Conservation Division
P.O. Box 1980
Albuquerque, NM 88241

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Nearburg Producing Company

3. Address and Telephone No.

3300 N A St., Bldg 2, Suite 120, Midland, TX 79705 915/686-8235

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FNL and 1,650' FWL, Section 34, T20S, R33E

5. Lease Designation and Serial No.

NMNM-77074

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Tomahawk 34 Federal #1

9. API Well No.

30-025-34302

10. Field and Pool, or Exploratory Area

Wildcat - Yates

11. County or Parish, State

Lea County, New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Nearburg Producing Company requests to Plug and Abandon the above well.

Estimated starting date: 01-04-99.

Proposed abandonment:

- 1). MIRU well service unit.
- 2). Set CIBP at 3,390' w/35' cement on top to abandon the Wildcat - Yates perforations at 3,467' - 3,494'.
- 3). Circulate hole w/salt gel mud (9.5# brine w/25# gel per barrel).
- 4). Spot 100' cement plug from 473' - 573' to abandon 16" casing shoe at 523'.
- 5). Spot 10 sx cement at surface to provide surface plug.
- 6). Install well marker and restore location.
- 7). RDMO.

14. I hereby certify that the foregoing is true and correct

Signed: *Alexis C. Swoboda*
(This space for Federal or State office use)

Title Manager of Drilling and Production

Date 12/30/98

Approved by (ORIG. SGD.) ALEXIS C. SWOBODA
Conditions of approval, if any:

Title PETROLEUM ENGINEER

Date JAN 12 1999

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side

