

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-3672

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</p>	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator JOHN H. HENDRIX	8. Farm or Lease Name STATE "X"
3. Address of Operator 403 WALL TOWERS WEST MIDLAND, TEXAS 79701	9. Well No. 1
4. Location of Well UNIT LETTER <u>L</u> , <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>16</u> TOWNSHIP <u>20 South</u> RANGE <u>37 East</u> NMPM.	10. Field and Pool, or Wildcat Eunice Monument
15. Elevation (Show whether DF, RT, GR, etc.) 3529' DF	12. County Lea

<p align="center">16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data</p>	
<p align="center">NOTICE OF INTENTION TO:</p> <p>PERFORM REMEDIAL WORK <input checked="" type="checkbox"/> PLUG AND ABANDON <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/></p>	<p align="center">SUBSEQUENT REPORT OF:</p> <p>REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/></p>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up service unit and pull tubing and rods.
2. Set RTBP at 3690'.
3. Perforate Grayburg formation from 3492' to 3681' with 11 jet shots.
4. Acidize with 5000 gallons 15% LSTNE acid.
5. Swab well to test and return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <u>Paula Pendleton</u>	TITLE <u>Accountant</u>	DATE <u>11-1-72</u>
APPROVED BY <u>John Runyan</u> Geologist	TITLE _____	DATE <u>NOV 1972</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

APR 10 1962

DL CONSERVATION COMM.
HELSINKI, FINL.