

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <u>John Hendrix Oil Co.</u>	8. Farm or Lease Name
3. Address of Operator	9. Well No.
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER <u>1</u> , <u>500</u> FEET FROM THE <u>S</u> LINE AND <u>600</u> FEET FROM	<u>Undesignated</u>
THE <u>32</u> LINE, SECTION <u>20</u> TOWNSHIP <u>36</u> RANGE <u>10</u> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
<u>3500'</u>	<u>100</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- This well is no longer producing. Propose to plug as follows:
1. Spot 25 sh plug 500' inside 5 1/2 csg on top of 31 30 Guiberson packer
  2. Shoot 5 1/2 csg - Free Point & pull est 5500'
  3. Spot 35 sh plug 5 1/2 csg stub
  4. Spot 35 sh plug 50' in 50' out of 3 5/8 shoe - 2000'
  5. Shoot 3 5/8 - Free Point & pull est 1500'
  6. Spot 35 sh plug 3 5/8" stub
  7. Spot 70 sh plug 50' in 50' out of 13 3/8 shoe - 2500'
  8. Place 10 sh plug in surface
  9. Direct dry hole marker

Note: All plugs spotted w/0.5% mudladen fluid between plugs

100' plug top Cement  
100' " " SA

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Aubrey E. Roney TITLE Prod Foreman DATE \_\_\_\_\_

APPROVED BY Joe D. Roney TITLE Dist. L. Supt. DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: