

NO. OF COPIES RECEIVED	
DISTRIBUTION	
ANTA FE	
ILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Nov 30 10 57 AM '65

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name	
8. Well No.	
10. Field and Pool, or Wildcat	
12. County	

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator		8. Farm or Lease Name	
Gulf Oil Corporation		H. T. Mattern (NCT-E)	
3. Address of Operator		8. Well No.	
Box 670, Hobbs, New Mexico		5	
4. Location of Well		10. Field and Pool, or Wildcat	
INITIALS E 2310 FEET FROM THE North LINE AND 330 FEET FROM		Arrowhead	
THE West LINE, SECTION 12 TOWNSHIP 22-S RANGE 36-E NMPM.			
15. Elevation (Show whether DF, RT, GK, etc.)		12. County	
3501 GL		Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>
Plug & Abandon	

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work.) SEE RULE 1103.

3785' TD.

It is proposed to plug and abandon as follows: Pull rods, pump and tubing. Set CI BP at 3650' on tubing. Displace hole with approximately 90 barrels of mud. Spot 7 sack, 50', cement cap on top of BP. Pull tubing to 50'. Set 7 sack, 50', plug from 50' to surface. Clean location and install regulation dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____ TITLE Area Petroleum Engineer DATE November 29, 1965

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: