

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
310 Old Santa Fe Trail, Room 206  
Santa Fe, New Mexico 87503

WELL API NO. 30-025-08935
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-1536
7. Lease Name or Unit Agreement Name State E
8. Well No. 1
9. Pool name or Wildcat Eunice 7RS-Qn So.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL, OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator Conoco Inc.	
3. Address of Operator 10 Desta Dr., Suite 100W, Midland, TX	
4. Well Location Unit Letter P : 660 Feet From The South Line and 660 Feet From The East Line Section 17 Township 22S Range 36E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3549' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set a C.I.B.P. at 3600' with 35' cement on top.
2. Circulate hole with gelled brine mud.
3. Perforate the 5½" casing at 1550'. Set a cement retainer at 1325' and squeeze 25 sxs cement.
4. Perforate 5½" casing at 435'. Circulate 90 sxs cement thru perfs to surface.
5. Install dryhole marker. Clean location.

THE COMPLETION MUST BE NOTIFIED 24  
HOURS PRIOR TO THE BEGINNING OF  
PLUGGING OPERATIONS FOR THE CARR  
TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Bern Fisher TITLE Field Supervisor DATE 8-2-99

TYPE OR PRINT NAME Bern Fisher TELEPHONE NO. (505) 392-6591

(This space for State Use)  
ORIGINAL SIGNED BY

GARY WINK  
FIELD REP. II

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE AUG 06 1999

CONDITIONS OF APPROVAL, IF ANY:

Je

dn