

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 407
7. Unit Agreement Name
8. Farm or Lease Name Lea 407 State
9. Well No. 3
10. Field and Pool, or Wildcat Eumont-Yates, 7R
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER - Temporarily Abandoned
2. Name of Operator Atlantic Richfield Company
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201
4. Location of Well UNIT LETTER X 660 FEET FROM THE South LINE AND 2310 FEET FROM THE West LINE, SECTION 2 TOWNSHIP 21-S RANGE 35-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3569' GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>	PLUG AND ABANDONMENT	<input type="checkbox"/>
CASING TEST AND CEMENT JOBS	<input type="checkbox"/>	OTHER	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has been temporarily abandoned since 11/17/55 and no secondary recovery possibilities have developed. We propose to P & A as follows:

1. Cut off and recover 7" casing from free point (top cmt @ 1210').
 2. Set 30 sk cement plug in and out of 7" stub.
 3. Set 30 sk cement plug across 10-3/4" shoe @ 308'.
 4. Place 10 sx cement in top of well.
- 9#/gal gel mud will be left between all plugs. 10-3/4" casing will remain intact. Dry hole marker will be erected. Location will be cleared & levelled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. D. Lutes

TITLE Dist. Drlg. Supervisor

DATE 7/9/71

APPROVED BY [Signature]

TITLE SUPERVISOR DISTRICT I

DATE JUL 12 1971

CONDITIONS OF APPROVAL, IF ANY:

1