District I		State of N Energy, Minerals an	iew M id Nati	lexico ural Re	esources				Rev	Frised M	orm C
1625 N. French Dr., Hobbs, NM 8 District II		OW					WELL A			LOCU IV.	larch 25,
811 South First, Artesia, NM 872	10	OIL CONSERVA			VISION		F 7 11		5-04558		
District III 1000 Rio Brazos Rd., Aztec, NM	87410	2040 Sou					ł .	ate Type			
District IV		Santa Fe,	NM 8	37505				TATE [EE []
2040 South Pacheco, Santa Fe, NN							6. State	Oil & Ga	s Lease N	o.	
DIFFERENT RESERVOIR. USE PROPOSALS.) 1. Type of Well:	E "APPLI	CES AND REPORTS OF COSALS TO DRILL OR TO DE CATION FOR PERMIT (FOR			G BACK TO SUCH	0 A			Unit Agr		nt Name
Oil Well X Gas We	11 🔲	Other					EUNICE	MONUMENT	SOUTH T	MIT	
2. Name of Operator Chevron U.S.A. Inc.							8. Weil	No.			
3. Address of Operator							335				
P.O. Box 1150 Midland,	TX 7	9702						name or W			
4. Well Location						1	EUNICE	MONOMENT	; CRAYBUR	G-SAI	I ANDRI
Unit Letter M	 :	feet from the	soc	лн	_ line and	i	660	_ feet fro	m the	WEST	<u> </u>
Section	8		1s	Range	365		NMPM		County	,	LEA
		10. Elevation (Show wh	hether .	DR, RK	(B, RT, G)	R, etc.	.)				
11 C	heck A	ppropriate Roy to I-1	ligate	NI-4	C > 7						
NOTICE OF	FINTE	ppropriate Box to Ind	ncate	Natur							
PERFORM REMEDIAL WORL	K [] 	PLUG AND ABANDON		DC: :-	S S	SUBS	SEQUE	NT REF	PORTC	F:	
	_			HEME	DIAL WO	RK			ALTER	ING C	ASING
TEMPORARILY ABANDON	X	CHANGE PLANS		сомм	IENCE DE	RILLIN	IG OPNS		PLUG /	AND	
DIO 1	_										
PULL OR ALTER CASING		MULTIPLE COMPLETION		CASIN CEMEI	G TEST A	AND			ABANC	MNO	ENT
OTHER: 12. Describe Proposed or Co	ompleted	COMPLETION Operations (Clearly state		OTHER	NT JOB		e pertinen	at dates, in			
PULL OR ALTER CASING OTHER: 12. Describe Proposed or Co of starting any proposed or recompilation. CHEVRON PROPOSES TO	ompleted work). S	COMPLETION I Operations (Clearly state SEE RULE 1103. For Mu		OTHER	NT JOB		e pertinen vellbore d	tt dates, in iagram of			
OTHER: 12. Describe Proposed or Concept starting any proposed on recompilation. CHEVRON PROPOSES TO Describe Proposes TO	ompleted work). S	COMPLETION Operations (Clearly state SEE RULE 1103. For Mu ATTACHED PROCEDURE.	e all pe	OTHER ertinent Comple	NT JOB R: details, ar tions: At	nd give tach w	vellbore d	D.	proposed		ed date letion
OTHER: 12. Describe Proposed or Concentrating any proposed or recompilation. CHEVRON PROPOSES TO Describe Proposed or Concentration of recompilation. CHEVRON PROPOSES TO Describe Proposed or Concentration of recompilation.	mpleted work). S	COMPLETION Operations (Clearly state SEE RULE 1103. For Mu ATTACHED PROCEDURE.	e all pe	OTHER ertinent Comple	NT JOB R: details, ar stions: At	nd give tach w	vellbore d	D.	proposed	stimat	ed date letion
OTHER: 12. Describe Proposed or Concentrating any proposed or recompilation. CHEVRON PROPOSES TO Describe Proposed or Concentration of recompilation. CHEVRON PROPOSES TO Describe Proposed or Concentration of recompilation.	mpleted work). S	COMPLETION Operations (Clearly state SEE RULE 1103. For Mu ATTACHED PROCEDURE.	e all pe	OTHER ertinent Comple	NT JOB R: details, ar stions: At	nd give tach w	vellbore d	D.	proposed	stimat	ed date letion
OTHER: 12. Describe Proposed or Confidence of starting any proposed on recompilation. CHEVRON PROPOSES TO Describe Proposed or Confidence of Starting any proposed of the starting any proposed of the starting any proposed of the starting any proposed or recompilation.	mpleted work). S	COMPLETION Operations (Clearly state SEE RULE 1103. For Mu ATTACHED PROCEDURE.	e all pe	OTHER ertinent Comple	NT JOB R: details, ar stions: At	nd give	vellbore d	D.	ATE	stimat	ed date letion

EMSU # 335

February 12, 2002

API # 30-025-04558 660' FSL & 660' FWL S8, T21S, R36E, & Unit M Eunice Monument South Unit Lea County, New Mexico

PROCEDURE TO TEMPORARILY ABANDON WELL:

Notify OCD/BLM 24 hrs prior to work commencing.

- 1. Verify anchors have been set & tested.
- 2. MIRU PU. NU BOP. Pull tbg and pump
- 3. TIH w/3-3/4" bit, csg scraper, & WS. Make bit trip to 3800'. POH.
- 4. Set 4.5" CIBP @ 3800'. Dump 2 sx Class 'C' cmt on CIBP. Test casing and plug to 500 psi.
- 3. TIH w/4-3/4" bit, csg scraper, & WS. Make bit trip to 3000'. POH.
- 4. Set 5.5" CIBP @ 3000'. Dump 3 sx Class 'C' cmt on CIBP.
- 5. TIH w/WS to TOC. Circulate csg w/corrosion inhibited pkr fluid. TOH.
- 6. Perform MIT (500 PSI for 30 min.).
- 7. ND BOP. NU WH. RD PU.
- 8. Clean and clear location.

K. Hickey 687-7260

