

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION N. O. C.

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

JAN 10 3 37 PM '66

5a. Indicate Type of Lease  
State ☒ Fee ☐

5. State Oil & Gas Lease No.

**B-1732**

### SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>Gulf Oil Corporation</b>	8. Farm or Lease Name <b>Harry Leonard (NCT-F)</b>
3. Address of Operator <b>Box 670, Hobbs, New Mexico</b>	9. Well No. <b>13</b>
4. Location of Well UNIT LETTER <b>Lot 2</b> , <b>990</b> FEET FROM THE <b>North</b> LINE AND <b>2310</b> FEET FROM THE <b>East</b> LINE, SECTION <b>2</b> TOWNSHIP <b>21-S</b> RANGE <b>37-E</b> NMPM.	10. Field and Pool, or Wildcat <b>Paddock</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3511 GL</b>	12. County <b>Los</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> <b>Plug and Abandon</b>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**5995' TD, 5808' PB.**

Run CI BP on tubing and set at approximately 5600'. Circulate hole with 145 barrels of mud. Spot 10 sack cement plug on top of BP. Test 5-1/2" casing with 500#. Pull tubing to 50' and spot 10 sack cement plug to surface. Install dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. D. P. [Signature] TITLE **Area Production Manager** DATE **January 14, 1966**

APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: