

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Bravo Operating Co.	8. Farm or Lease Name Hill
3. Address of Operator P. O. Box 2160 Hobbs, New Mexico 88241	9. Well No. 1
4. Location of Well UNIT LETTER <u>J</u> <u>3300</u> FEET FROM THE <u>North</u> LINE AND <u>1730</u> FEET FROM THE <u>East</u> LINE, SECTION <u>4</u> TOWNSHIP <u>21S</u> RANGE <u>37E</u> NMPM.	10. Field and Pool, or Wildcat Blinebry
15. Elevation (Show whether DF, RT, GR, etc.) 3435' GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set CIBP @ 5600'±. Cap with 2 sx cement.
- Displace hole with salt gel mud.
- Set 25 sx cement plug @ 4250-4000'.
- Set 25 sx cement plug @ 2900-2650'. - MUST PERFORM
- Set 25 sx cement plug @ 1500-1250'. - MUST PERFORM THROW IN 2 STRINGS OF PIPE
- Set 10 sx plug @ surface.
- Install dry hole marker.
- Restore location and ready for final inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE NRE, Agent for Bravo Operating DATE April 30, 1987

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

DATE MAY 11 1987

APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED  
MAY 8 1987  
OCD  
HOBBS OFFICE