

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions on
reverse side)

Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-2512

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

NORTHEAST DRINKARD UNIT

8. FARM OR LEASE NAME

NORTHEAST DRINKARD UNIT

9. WELL NO.

406

10. FIELD AND POOL OR WILDCAT
NORTH EUNICE BLINEBRY-
TUBB-DRINKARD OIL & GAS

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

SEC. 10, T21S, R37E

12. COUNTY OR PARISH 13. STATE

LEA

NM

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

SHELL WESTERN E&P INC.

3. ADDRESS OF OPERATOR

P. O. BOX 576, HOUSTON, TEXAS 77001 (WCK 4435)

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

990' FNL & 1650' FEL SEC. 10

14. ~~XXXXXX~~ API NO.

30-025-06451

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3434' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other) Identify PBTD: Log

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS. Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.*

1. POH w/prod equip.

2. Tag PBTD.

3a. If PBTD is above 6700':

CO to 6700'. Set pkr @ 6650'. Pres tst to 500#. POH w/pkr.

3b. If PBTD is below 6700':

Set pkr @ 6650'. Pres tst to 500#. POH w/pkr.

4. Run GR/CNL/CCL from PBTD to 5550'.

5. Perf Blinebry/Tubb/Drinkard @ depths determined from log eval.

6. Acidz Blinebry/Tubb/Drinkard perms using RBP & pkr. Treatment sch based on log eval.

7. POH w/RBP & pkr.

8. Install prod equip & ret well to prod.

18. I hereby certify that the foregoing is true and correct

SIGNED A. J. FORE

TITLE SUPERVISOR REG. & PERMITS

DATE 8-19-88

(This space for Federal or State office use)

APPROVED BY GENERAL RESOURCES

TITLE

DATE 9-19-88

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

RECEIVED

SEP 21 1988

OCD
NOBBS OFFICE