

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

HOBBS OFFICE D. C. C.  
NEW MEXICO OIL CONSERVATION COMMISSION  
JUN 5 11 02 AM '69

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

### SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>Wolfson Oil Company</b>	8. Farm or Lease Name <b>Shell-Waldrap</b>
3. Address of Operator <b>3206 Republic Park Tower Dallas, Texas</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>L</b> , <b>650</b> FEET FROM THE <b>West</b> LINE AND <b>1230</b> FEET FROM THE <b>South</b> LINE, SECTION <b>6</b> TOWNSHIP <b>20S</b> RANGE <b>39E</b> NMPM.	10. Field and Pool, or Wildcat <b>House (Drinker)</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3577 Lr.</b>	12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Request permission to plug and abandon by setting 25 sx cement above bottom perforations at 7070-90 feet.  
Set 25 sx plug at place where 5 1/2" casing is out at approximately 3500'  
Set 5 sx plug at surface of 7 5/8 intermediate which is cemented from surface to 3174'.  
Install appropriate marker.

25 sxs in & out of 7 5/8 shoe  
10 " @ surface

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Prod. Engr. DATE 6-4-69

APPROVED BY [Signature] TITLE ASST. MGR. DATE 6-4-69

CONDITIONS OF APPROVAL, IF ANY: