

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Summit Energy, Inc.		8. Farm or Lease Name Gulf Hill
3. Address of Operator 112 N. First, Artesia, New Mexico 88210		9. Well No. 4
4. Location of Well UNIT LETTER <u>S</u> <u>1980</u> FEET FROM THE <u>West</u> LINE AND <u>1980</u> FEET FROM THE <u>South</u> LINE, SECTION <u>4</u> TOWNSHIP <u>21S</u> RANGE <u>37E</u> N.M.P.M.		10. Field and Pool, or Wildcat Drinkard - Blinebry Wantz Abo
15. Elevation (Show whether DF, RT, GR, etc.) 3476 GR		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is our intention to plug and abandon the subject well as follows:

1. Place a 200 foot cement plug over the Drinkard Perfs, a 200 foot cement plug over the Blinebry Perfs and a 200 foot cement plug over the Wantz Abo Perfs.
2. We will place a 100' plug at the stub of 2 7/8" tubing
3. We will place a 100' cement plug in and out of the 10 3/4" casing at 2940'.
4. We will erect proper marker and put a 10 sack cement plug at top of 10 3/4" casing.
5. We will clean location for inspection by NMOCC.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Paul White</u>	TITLE <u>Division Engineer</u>	DATE <u>8/28/74</u>
APPROVED BY <u>Joe D. Roney</u>	TITLE <u>Dist. Eng. Supr.</u>	DATE <u>8/28/74</u>
CONDITIONS OF APPROVAL, IF ANY:		