

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>SunOil Company</b>		8. Name of Lease Owner <b>J. A. Akens</b>
3. Address of Operator <b>P. O. Box 2792, Odessa, Texas 79760</b>		9. Well No. <b>8</b>
4. Location of Well UNIT LETTER <b>W</b> <b>889.1</b> FEET FROM THE <b>South</b> LINE AND <b>2289.3</b> FEET FROM THE <b>East</b> LINE, SECTION <b>3</b> TOWNSHIP <b>21 S</b> RANGE <b>36 E</b> N.M.P.M.		10. Field and Pool, or Wildcat <b>Oil Center-Blinebry</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>Gr. 3558</b>		11. County <b>Lee</b>

### 16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <b>Perf. and acidize</b>		OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Move in service rig, kill well w/treated wtr, install BOP, check PBD, pull tubing. Perf. casing @ 6129, 33, 37, 48, 71, 78, 82, 84(9 holes by Sonic). Run tubing and packer to 6200, spot 500 gals 15% NE, raise and set pkr at 6110. Acidize perfs. 6129-6184 with total 1500 gals 15% NE using ball sealers. Raise and set pkr at 5800, acidize all perfs. 5829-6184 w/2000 gals 15% NE and ball sealers. Swab and test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John M. Swanson TITLE Asst District Superintendent DATE 1-7-70  
APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: