

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. OIL CONS. COMMISSION
P.O. BOX 980
HOBBS, NEW MEXICO 88240

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Collins & Ware, Inc.

3. Address and Telephone No.

303 W. Wall, Suite 2200, Midland, Texas 79701

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

330' FSL & 140' FWL of Section 31, T-21S, R-32E, Unit letter M

5. Lease Designation and Serial No.

NM85932

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

BW "31" Federal No. 1

9. API Well No.

30-025-31394

10. Field and Pool, or Exploratory Area

West Tank Delaware
Under Livingston Ridge

11. County or Parish, State

Lea, New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Below is the proposed plugging program for the BW "31" Federal No. 1. Please let me know if you have any questions, changes, or need any additional information.

Set CIBP @ 7120' w/ 50' cement on top. Set CIBP @ 4000' w/ 50' cement on top. Stretch 5 1/2" casing for freepoint and cut off same. Lay down casing. Run tubing and spot 50 sx cement plug from 850' to 750' shoe. Spot 50' plug at surface. Cut off wellhead. Install dry hole marker & clean area as per BLM requirements.

① SET 140' CEMENT PLUG (70' BELOW TO 70' ABOVE CASING STUB. TAG PLUG.

② TAG PLUG.

RECEIVED

APR 15 11 50 AM '94

CANON AREA

APR 8 3 07 PM '94
BUREAU OF LAND MGT
ROSWELL RESOURCE
AREA

RECEIVED

14. I hereby certify that the foregoing is true and correct

Signed

Title

Dianne Sumrall
Production Anylist

Date

4/5/94

(This space for Federal or State office use)

Approved by

Title

Date

4/29/94

Conditions of approval, if any:

- SEE ATTACHED -