

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-09288
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	7. Lease Name or Unit Agreement Name State A AC 1
2. Name of Operator Clayton Williams Energy, Inc.	8. Well No. 9
3. Address of Operator Six Desta Drive, Suite 3000 Midland, Texas 79705	9. Pool name or Wildcat Jalmat Tansill Yates 7 Rvrs
4. Well Location Unit Letter M : 660 Feet From The South Line and 660 Feet From The West Line Section 9 Township 23S Range 36E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) GR - 3496	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER: <input type="checkbox"/>	SUBSEQUENT REPORT OF: REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. Work will commence upon OCD approval

- 1) CIBP set @ 3150' w/35' of cement on CIBP (04/08/94)
- 2) Circulate hole w/10 PPG gelled brine from CIBP to surface
- 3) Perforate 5-1/2" casing @ 525'.
- 4) Circulate cement down 5-1/2" casing and up the 5-1/2"/10" annulus to surface.
(185 sx Class "C" cement w/2% CaCl2)
- 5) Cut 5-1/2" and 10" casing 3' below GL. Set P & A marker. Cut deadmen.
Remove all junk from location. **Plug and Abandon Wellbore**

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE David G. Grafe TITLE Senior Operations Engineer DATE 09/01/94
TYPE OR PRINT NAME David G. Grafe TELEPHONE NO. 682-6324

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

SEP 06 1994