

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator SOHIO PETROLEUM COMPANY	8. Farm or Lease Name Mattern
3. Address of Operator P. O. Box 3000, Midland, Texas 79701	9. Well No. 6
4. Location of Well UNIT LETTER M 330 FEET FROM THE South LINE AND 330 FEET FROM THE West LINE, SECTION 7 TOWNSHIP 22S RANGE 37E NMPM.	10. Field and Pool, or Wildcat Arrowhead, Grayburg
15. Elevation (Show whether DF, RT, GR, etc.) 3445' D.F.	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was first temporarily abandoned in 1963. Unsuccessful attempts were made to restore production in May, 1968 and July, 1974, uneconomical to produce. Final T. A. date 9-7-74.

PROPOSED WORK:

**Set 100' cement plug above 3647 - 3740 open hole, plug from 3547 - 3647'.
Cut off 5 1/2" casing about 1500'.
Place 100' cement plug 1450 - 1550' (50' in and 50' out of casing).
Place 100' cement plug above salt, 980' - 1080'.
Place 100' cement plug 50' in and 50' out of surface, 250-350'.
Place 10 sack cement plug at surface.
Mud laden fluid to be placed between plugs.
This work will start on or before 10-1-75.**

Expires 12/1/75

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.H. Walters **J.H. Walters** TITLE District Superintendent **District Superintendent**
Midland District **Midland District** DATE December 4, 1974 **December 4, 1974**

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: