

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator GULF OIL CORPORATION		8. Farm or Lease Name H.T. Mattern (NCT-D)
3. Address of Operator P. O. Box 670, Hobbs, New Mexico 88240		9. Well No. 3
4. Location of Well UNIT LETTER <u>F</u> , <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>1650</u> FEET FROM THE <u>West</u> LINE, SECTION <u>7</u> TOWNSHIP <u>22-S</u> RANGE <u>37-E</u> N.M.P.M.		10. Field and Pool, or Wildcat Arrowhead
15. Elevation (Show whether DF, RT, GR, etc.) 3441' GL		12. County Lea

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

3750' TD.

Pull rods and pump. Spot 100' plug at approximately 2950'. Tag plug. Load hole with abandonment mud. Spot 100' cement plug across base of salt at 2440'. Spot 100' cement plug across top of salt at 1200'. Pull 5-1/2" casing at 400'. Spot cement plug from 450' to surface. Install dry hole marker. Clean and clear location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. B. Sisk TITLE Area Engineer DATE 07-12-78

APPROVED BY Jerry Sexton TITLE Dist. Eng. DATE 12-13-78

CONDITIONS OF APPROVAL, IF ANY Expires 1/13/79

RECEIVED

JUN 13 1978

CH. CONSTRUCTION CO. INC.  
NEW YORK, N. Y.