

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE
(Other instructions on reverse side)

Form approved
Budget Bureau No. 42-11124
5. LEASE DESIGNATION AND SERIAL NO.

LC-033706-B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

S. Penrose Skelly Unit

8. FARM OR LEASE NAME

9. WELL NO.

181

10. FIELD AND TOOL, OR WILDCAT

Penrose Skelly

11. SEC. T. R. M. OR R.R. AND SURVEY OR AREA

Sec 8-22S-37E

12. COUNTY OR PARISH 13. STATE

Lea NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
Gulf Oil Corporation

3. ADDRESS OF OPERATOR

P. O. Box 670, Hobbs, NM 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface

1980
660' FSL + 660' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, ST, CR, etc.)

3418' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

Cap CIBP @ 3475' w/ 35' cmt. Circ hole w/ abandonment mud.
Spot 100' cmt plug @ 2425'. Perf @ 1300' w/ (4) 1/2" JH. Pmp
dn csg + circ fluid out csg-csg ann. Set cmt ret @ 1200'.
1st try 3000#. Establish rate + press. Pmp 300 sx cmt + circ
to surf. Close surf csg valve + sg to 500# above pmp - in
press. Pull out of ret, cap w/ 2 sx cmt. Run excess cmt.
Spot 50' surf plug. Install dry hole marker. Clear +
clear location.

18. I hereby certify that the foregoing is true and correct

SIGNED

R. D. Pite

TITLE

Area Engineer

DATE

6-5-84

(This space for Federal or State office use)

APPROVED BY

R. D. Pite

TITLE

P. E.

DATE

6/15/84

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED
JUN 18 1984
C.C.B.
HCEES OFFICE