

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. <b>30-025-10367</b>
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. <b>B-934</b>
7. Lease Name or Unit Agreement Name <b>NEW MEXICO "M" STATE</b>
8. Well No. <b>33</b>
9. Pool name or Wildcat <b>LANGLIE MATTIX</b>
10. Elevation (Show whether DF, RKB, RT, GR, etc.) <b>3435' DF</b>

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <b>WATER INJECTION</b>
2. Name of Operator <b>GP II ENERGY, INC.</b>
3. Address of Operator <b>PO BOX 50682 MIDLAND, TEXAS 79710</b>

4. Well Location Unit Letter <b>"K"</b> : <b>1980</b> Feet From The <b>South</b> Line and <b>1880</b> Feet From The <b>West</b> Line Section <b>19</b> Township <b>22-S</b> Range <b>37-E</b> NMPM <b>LEA</b> County
--

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**GP II PLANS TO START PLUGGING PROCEDURES ON THIS WELL IN APPROX. 60 DAYS.**

1. MOVE IN AND RIG UP
2. SET CIBP @ 3538' (100' above perfs @ 3638' - 3752')
3. PERFORATE 2-7/8" TUBING @ 2440' AND SET 25 sxs CEMENT PLUG - TAG
4. PERFORATE 2-7/8" TUBING @ 1100' AND SET 25 sxs CEMENT PLUG - TAG
5. SET PLUG AT 333' - 233' AND TAG (Surface Casing @ 283')
6. SET 60' PLUG AT SURFACE
7. CLEAN LOCATION AND MOVE OFF.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Tonya Garza* TITLE Production Analyst DATE 03-08-2001  
TYPE OR PRINT NAME TONYA GARZA TELEPHONE NO. 915-684-4748

(This space for State Use)

APPROVED BY \_\_\_\_\_ TITLE ORIGINAL DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE CHOO TO BE APPROVED