

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

JUN 24 11 45 AM '66

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		5. State Oil & Gas Lease No.
2. Name of Operator Anadarko Production Company		7. Unit Agreement Name Langlie Mattix Penrose Sand Unit
3. Address of Operator P. O. Box 247, Hobbs, New Mexico		8. Farm or Lease Name Tract No. 19
4. Location of Well UNIT LETTER J 1980 FEET FROM THE East LINE AND 1980 FEET FROM THE South LINE, SECTION 27 TOWNSHIP 22 S RANGE 37 E NMPM.		9. Well No. 1
15. Elevation (Show whether DF, RT, GR, etc.) 3229' GR		10. Field and Pool, or Wildcat Langlie Mattix
		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
 NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> OTHER <input type="checkbox"/>
---	---	--	---

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set a plug and spot 25 sks cmt in 7" casing at 3375'.
2. Pull 7" casing from approximately 2000'.
3. Set a plug and spot 25 sks cmt in top of 7" stub.
4. Set a plug and spot 25 sks. cmt in bottom of 8-5/8" casing set at 1185'.
5. Spot 10 sks cmt in top of 8-5/8" casing at surface. Place 4" hole marker.
6. Level and clear location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED M. J. Nelson TITLE Project Supervisor DATE 6/23/66

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: