

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator MORANCO		8. Farm or Lease Name Xmas	
3. Address of Operator P. O. Box 1860, Hobbs, New Mexico		9. Well No. 1	
4. Location of Well UNIT LETTER H, 2310 FEET FROM THE North LINE AND 660 FEET FROM East THE LINE, SECTION 29 TOWNSHIP 22S RANGE 38E NMPM.		10. Field and Pool, or Wildcat Drinker	
15. Elevation (Show whether DF, RT, GR, etc.) 3381 KB 3371 GL		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Move in unit to Plug and Abandon well.

1. Set bridge plug on wire line @ 6800'± cap with 35' (3 sacks) cement.

2. Pull what casing is available.
(calculated top of cement is 3930')

3. After pulling casing, go in hole with tubing, displace hole with mud.

4. Set 50 sack plug across casing stub.

5. Set 75 sack plug from 2400' to 2700'.

6. Set 100 sack plug from 1200' to 1500'. THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

7. Set surface plug and dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Joe T. Janica
Joe T. Janica, Dict. I, Supv.

TITLE Agent

DATE March 31, 1976

APPROVED BY _____

TITLE _____

DATE APR 5 1976

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JUL 10 1978

CAL CONSERVATION COMM.
FISHER, H. M.