

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator Southwestern Natural Gas, Inc.		8. Farm or Lease Name Karoles
3. Address of Operator 900 Building of the Southwest Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER <u>L</u> <u>990</u> FEET FROM THE <u>west</u> LINE AND <u>2000</u> FEET FROM THE <u>south</u> LINE, SECTION <u>23</u> TOWNSHIP <u>22-S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat Drinkard
15. Elevation (Show whether DF, RT, GR, etc.) 3326' GL		12. County Lea

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Spot 50 sack cement plug from 6600' back to 6200' and from 5300' back to 4900' in 5-1/2" casing.
- Shoot 5-1/2" casing off at approximately 2000' and spot 50 sack plug at in/out cut-off point.
- Spot 75 sack plug from 1200' back to 1070' in 11" hole and 8-5/8" casing.
- Spot 10 sack plug at surface, set marker and clear and abandon location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Dm C. Penner TITLE Operations Manager DATE 3-17-70

APPROVED BY John W. Runyan TITLE Geologist DATE 3/17/70

CONDITIONS OF APPROVAL, IF ANY: