

OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name Parks
9. Well No. 9
10. Field and Pool, or Wildcat Drinkard
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator Cleary Petroleum Corporation 3. Address of Operator 200 Gihls Tower West, Midland, Texas 79701 4. Location of Well UNIT LETTER N, 660' FEET FROM THE south LINE AND 1980 FEET FROM THE west LINE, SECTION 14 TOWNSHIP 22S RANGE 37E NMPM. 15. Elevation (Show whether DF, RT, GR, etc.)

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

<p>NOTICE OF INTENTION TO:</p> <p>PERFORM REMEDIAL WORK <input checked="" type="checkbox"/> PLUG AND ABANDON <input type="checkbox"/> REMEDIAL WORK <input type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/></p> <p>PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>	<p>SUBSEQUENT REPORT OF:</p> <p>ALTERING CASING <input type="checkbox"/></p> <p>PLUG AND ABANDONMENT <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>
---	---

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Kill well and pull tubing. Set BP at 4075'. Perforate 4JS at 4015'. Run tubing with retrievable cementer and set above perforation at 4015'. Block squeeze with 800 sacks cement. Drill out to BP and test perforations. Re-squeeze if necessary. Run cement bond-log. Drill out BP. Run production string.

We propose to start this work around December 15, 1974.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Mary Ann Ferguson</u>	TITLE <u>Production Clerk</u>	DATE <u>11/12/74</u>
APPROVED BY <u>Joe</u>	TITLE <u>Director</u>	DATE <u>11/12/74</u>

CONDITIONS OF APPROVAL, IF ANY: