

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator John H. Hendrix		8. Farm or Lease Name Cossatot "G"
3. Address of Operator 403 Wall Towers West, Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER <u>F</u> , <u>2310</u> FEET FROM THE <u>North</u> LINE AND <u>1650</u> FEET FROM THE <u>West</u> LINE, SECTION <u>13</u> TOWNSHIP <u>22-S</u> RANGE <u>37-E</u> NMPM.		10. Field and Pool, or Wildcat Drinkard
15. Elevation (Show whether DF, RT, GR, etc.) 3315' GL		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up Well Service pulling unit.
2. Run tubing and set retrievable bridge plug @ 6550'.
3. Spot 400 gallons of 15% LSTNE acid. Pull tubing.
4. Perforate @ 6246', 6265', 6276', 6293', 6303', 6316', 6341', 6360', 6378', 6394', 6408', 6422', 6440', 6457', and 6473' with 1 3/8" jet per interval.
5. Acidize with 5,400 gallons 15% LSTNE acid.
6. Swab to test well.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Paula P. Henderson</u>	TITLE <u>Accountant</u>	DATE <u>6-5-73</u>
APPROVED BY <u>[Signature]</u>	TITLE <u></u>	DATE <u>JUN 14 1973</u>
CONDITIONS OF APPROVAL, IF ANY:		