

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEW OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <u>John H. Hendrix</u>		8. Farm or Lease Name <u>Cossatot "F"</u>
3. Address of Operator <u>403 Wall Towers West, Midland, Texas 79701</u>		9. Well No. <u>4</u>
4. Location of Well UNIT LETTER <u>F</u> . <u>1650</u> FEET FROM THE <u>north</u> LINE AND <u>1980</u> FEET FROM THE <u>west</u> LINE, SECTION <u>23</u> TOWNSHIP <u>22-S</u> RANGE <u>37-E</u> NMPM.		10. Field and Pool, or Wildcat <u>Drinkard</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>3334'</u>		12. County <u>Lea</u>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPERATIONS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Dual complete Drinkard</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

1. Rig up pulling unit, pull tubing and packer.
2. Perforate from 6190-6932' w/27 jet shots.
3. Acidize w/5,000 gals. 15% LSTNE. Frac with 60,000 gals. gelled lease crude and 60,000# sand.
4. Run tubing and packer.
5. Test well.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Charles E. Jones TITLE Production Clerk DATE 11-29-73

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: