

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Encl Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-27684
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-2799
7. Lease Name or Unit Agreement Name Tophat AJQ State
8. Well No. 1
9. Pool name or Wildcat Wildcat Bone Springs
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3639' GR

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL WELL ☒ GAS WELL ☐ OTHER

2. Name of Operator  
YATES PETROLEUM CORPORATION

3. Address of Operator  
105 South 4th St., Artesia, NM 88210

4. Well Location  
Unit Letter H : 1980 Feet From The North Line and 660 Feet From The East Line  
Section 35 Township 23S Range 33E NMPM Lea County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: Test Bone Springs sand ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to test Bone Springs Sand for oil productivity as follows:

1. Install BOP. TOOH with tubing. TIH with bit, drill collars and tubing. Drill out and clean hole to 10100'. Run GR/CCL/CBL log.
2. Perforate Bone Springs sand from 9529-9630' w/20 holes.
3. TIH with RBP and packer. Set RBP at 9750' and test. Spot 2-3 sx of sand on top of RBP. Set packer at 9400' and test annulus.
4. Acidize perforations 9529-9630' as necessary.
5. Swab test. May frac if necessary.
6. Put well on pump if commercially oil productive.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE 11-21-95  
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for Stamp)  
ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE DEC 08 1995  
CONDITIONS OF APPROVAL, IF ANY: