

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease. State <input type="checkbox"/> Fed. <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. LC-069515
7. Unit Agreement Name
8. Farm or Lease Name North El Mar Unit
9. Well No. 24
10. Field and Pool, or Wildcat El Mar Delaware
12. County Lea

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Injection shut-in
2. Name of Operator CONOCO INC.
3. Address of Operator P. O. Box 460, Hobbs, N.M. 88240
4. Location of Well UNIT LETTER L , 1980 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 25 TOWNSHIP 26S RANGE 32E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> temporary abandon

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

- ① MIRU. POOH w/ injection equip. Run bit & scraper to perfs.
- ② Set CIBP @ 4550'. Test CIBP to 1000 psi. Load & press. test csg to 600 psi. for 10 minutes. If csg doesn't test, a sqz procedure will follow.
- ③ Circ. hole full of 9.0 ppg brine (pkr fluid).
- ④ Rig down

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED **Cecil O. Spaulding** TITLE **Administrative Supervisor** DATE **11-6-86**

APPROVED BY **[Signature]** TITLE **[Signature]** DATE **[Signature]**

CONDITIONS OF APPROVAL, IF ANY:

NMOCO-Hobbs

RECEIVED
NOV 7 1986
GEOLOGICAL
SURVEY OF CANADA