

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|---|----------------------------------|
| 1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- SWD | 7. Unit Agreement Name |
| 2. Name of Operator Millard Deck Estate | 8. Farm or Lease Name Steeler |
| 3. Address of Operator P. O. Box 2546, Fort Worth, Texas 76113 | 9. Well No. 1 |
| 4. Location of Well UNIT LETTER I 1980 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 20 TOWNSHIP 23S RANGE 37E NMPM. | 10. Field and Pool, or Wildcat |
| 15. Elevation (Show whether DF, RT, GR, etc.) | 12. County Lea |

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

| | | | |
|--|--|---|---|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> | CASING TEST AND CEMENT JOB <input type="checkbox"/> | |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

- (1) Pull out of hole with tubing and packer
- (2) Set Cement Plug 3340' - 3440' (100' above perms)
- (3) Cut 5½" casing off @ approximately 2000',
100' cement plug 50' in & 50' out of casing stub
- (4) Pull 5½" casing
- (5) Set cement Plug from 200' to 320' (50' in and 50' out of surface casing)
- (6) Set cement plug in top of surface pipe to 10'
- (7) Cut off Pipe below plow depth.

WELL NO. 1
COUNTY OF LEA
TOWNSHIP 23S
RANGE 37E
SECTION 20
APPROVED

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ed DiRe Ed DiRe TITLE Petroleum Engineer DATE 5/21/86

ORIGINAL SIGNED BY JERRY SEXTON

DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE MAY 26 1986

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED
MAY 26 1986
O.C.D.
HOBBS OFFICE