

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

OCT 12 3 43 PM '65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator <b>Gulf Oil Corporation</b>		8. Farm or Lease Name <b>Saltmount</b>
3. Address of Operator <b>P. O. Box 980, Kermit, Texas</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>P</b> , <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM <b>East</b> LINE, SECTION <b>21</b> TOWNSHIP <b>23S</b> RANGE <b>37E</b> NMPM.		10. Field and Pool, or Wildcat <b>Teague McKee</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3303' GR</b>		12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to pull tubing with packer and flow valves. Spot 40 sacks cement plug from 9410' to 9193' and fill hole with mud. Shoot 7" casing at 3730' and pull. Spot 25 sacks cement from 3755' to 3695'. Shoot 9 5/8" casing @ 1100' and pull. Spot 40 sacks cement from 1125' to 1065'; 40 sacks cement from 336' to 286', and 50' to surface. Leaving 5870' of 7" casing, 1802' of 9 5/8" casing and 311' of 13 3/8" casing in the hole. Set well marker and clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED H. J. Swannick TITLE Area Production Manager DATE October 12, 1965

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: