

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE
(Other instructions on
reverse side)

Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

030177 (B)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Storage

2. NAME OF OPERATOR
El Paso Natural Gas Company

3. ADDRESS OF OPERATOR
1800 Wilco Bldg. Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
2310 FSL, 330 FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether depth, RT, etc.)
2971 (G) HOSBS, NEW MEXICO

7. UNIT AGREEMENT NAME
Rhodes Storage

8. FARM OR LEASE NAME
Shepherd "B"

9. WELL NO.
1

10. FIELD AND POOL, OR WILDCAT
Rhodes-Yates-7 Rivers

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec 5, T-26-S, R-37-E

12. COUNTY OR PARISH
Lea

13. STATE
NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Rig up pulling unit, load tbq with water, pressure test, kill well with brine, displace 50 sx across perfs and 100' above, pull & stand back 10 stands, rn work string, tag top of cement, displace with mud on top of cement, spot 15 sx top plug of cement 150' to surface, weld plate on surface casing, set marker & clean up location.

AMENDMENT: 1. Place additional 40-sack plug in interval 2600-2800 feet.

2. 7" and 9" casing should be cut and pulled from 1200' if possible and a 50-sack cement plug placed in interval 1000 to 1200 feet. If casing cannot be pulled, place 50-sack cement plug inside 7" casing in interval 1000 to 1200 feet.

ILLEGIBLE

18. I hereby certify that the foregoing is true and correct

SIGNED *C.D. Ryan*

TITLE Production Clerk

DATE 5-1-75

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

*See Instructions on Reverse Side

