

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TR
(Other instruct
verse side)CATE*
on re-Form approved.
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

LC 063557

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Temporarily Abandoned		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR Atlantic Richfield Company		8. FARM OR LEASE NAME Parcel 1 Parcel 1	
3. ADDRESS OF OPERATOR P. O. Box 1978, Roswell, New Mexico 88201		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FSL & 660' FEL (Unit Letter I)		10. FIELD AND POOL, OR WILDCAT Drinkard	
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 6, T23S, R38E	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3360' GR		12. COUNTY OR PARISH Lea	
		13. STATE N.M.	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was temporarily abandoned in 1961 after a recom-
pletion attempt in the Tubb proved unsuccessful. We propose
to P & A as follows:

Shoot off and recover 7" from free point (top of cement @ 3300')
Spot these cement plugs:
35 sx in & out of 7" stub
35 sx across 9-5/8" shoe @ 2961'
10 sx in top of well

9#/gal gel mud will be left between all plugs. 9-5/8" &
13-3/8" casing strings will remain intact. A dry hole marker
will be erected and location cleared & leveled.

18. I hereby certify that the foregoing is true and correct

SIGNED

C. D. Satchel

TITLE

Dist. Drlg. Supervisor

DATE

8/26/71

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED
AUG 30 1971THUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse

RECEIVED

SEP 7 1971

OIL CONSERVATION COMM.
HOBBS, N. M.