

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

0-6-NMOCD-_____ 1-File

2-Midland-_____ 1-Engr. _____

1-Foreman-_____

Form C-103
Revised 10-1-71

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-_____	7. Unit Agreement Name W. Dollarhide Queen San
2. Name of Operator Getty Oil Company	8. Farm or Lease Name W. Dollarhide Queen San
3. Address of Operator P.O. Box 730, Hobbs, New Mexico 88240	9. Well No. 61
4. Location of Well UNIT LETTER <u>L</u> <u>2310</u> FEET FROM THE <u>South</u> LINE AND <u>990</u> FEET FROM THE <u>West</u> LINE, SECTION <u>5</u> TOWNSHIP <u>25S</u> RANGE <u>38E</u> NMPM.	10. Field and Pool, or Wildcat Dollarhide Queen
15. Elevation (Show whether DF, RT, GR, etc.) 3120' DF	12. County

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up install BOP and pull all production equipment.
2. Set 5 1/2" CIBP at \pm 3375' with 25 sxs on top.
3. Spot cement plug '2615-2715'; 10 sxs.
4. Perforate two holes at \pm 320'.
5. Cement down 5 1/2" casing and up 8 5/8" - 5 1/2" annulus until cement is circulated.
6. Install dryhole marker..
7. Clean and restore location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PRODUCTION OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Dale R. Crockett TITLE Area Superintendent DATE 2/15/84

APPROVED BY Jerry Sexton ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR

DATE MAR 1 1984

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

FEB 29 1984

O.C.D.
HOBBS OFFICE