

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input type="checkbox"/>
5. State 3-9312 Gas Lease No.
6. Name of Operator
7. Name of Lessee
8. Name of Landowner
9. Well No.
10. Location of Well
11. Elevation (Show whether Depth or Surface)
12. County

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	West Dollardhide Queen Sand Unit
2. Name of Operator	West Dollardhide Queen Sand Unit
3. Address of Operator	
4. Location of Well	
UNIT LETTER E FEET FROM THE 1942 LINE AND 660 FEET FROM West 5 25S 38E	Dollardhide Queen
THE _____ LINE, SECTION _____ TOWNSHIP _____ RANGE _____ NMPM.	
15. Elevation (Show whether Depth or Surface)	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is in the lower one-third of the unit area in which water break through problems have been experienced. The cost of operating wells in this area has become excessive, and we propose plugging this well as follows:

- 1) Rig up pulling unit. Pull tubing and packer.
- 2) Set 7" bridge plug at 3580'.
- 3) Circulate hole with 10# mud.
- 4) Spot 10 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement across top of salt section at 1240'.
- 6) Spot 10-sack cement plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10# mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>J. R. Avent</u>	TITLE <u>Dist. Admin. Coordinator</u>	DATE <u>Nov. 20, 1972</u>
APPROVED BY <u>Joe D. Ramey</u>	TITLE <u>Dist. J. Supv.</u>	DATE <u>NOV 22 1972</u>

CONDITIONS OF APPROVAL, IF ANY