

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-9312	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Skelly Oil Company		West Dollarhide Queen Sand Unit
3. Address of Operator		9. Well No.
P. O. Box 1351, Midland, Texas 79701		56
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER H 1980 FEET FROM THE North LINE AND 990 FEET FROM		Dollarhide Queen
THE East LINE, SECTION 5 TOWNSHIP 25S RANGE 38E NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3162' DF		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is in the lower one-third of the unit area in which water break through problems have been experienced. The cost of operating wells in this area has become excessive, and we propose plugging this well as follows:

- 1) Rig up pulling unit. Pull tubing and packer.
- 2) Set 5-1/2" bridge plug at 3595'.
- 3) Circulate hole with 10# mud.
- 4) Spot 10 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement across top of salt section at 1252'.
- 6) Spot 10-sack cement plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10# mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED (S) J. R. Avent	TITLE Dist. Admin. Coordinator	DATE Nov. 20, 1972
Orig. Signed By Joe D. Ramey		
APPROVED BY Dist. I. Supv.	TITLE	DATE NOV 22 1972
CONDITIONS OF APPROVAL, IF ANY:		