

Submit 3 Copies To Appropriate District
Office

District I
1625 N. French Dr., Hobbs, NM 87240

District II
811 South First, Artesia, NM 87210

District III
1000 Rio Brazos Rd., Aztec, NM 87410

District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
E. gy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

Form C-103

Revised March 25, 1999

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-025-12437
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator HENRY PETROLEUM LP		6. State Oil & Gas Lease No. B-9521
3. Address of Operator 3525 ANDREWS HIGHWAY - SUITE 200 MIDLAND TX 79703-5000		7. Lease Name or Unit Agreement Name SOUTH JUSTIS UNIT "I"
4. Well Location Unit Letter <u>D</u> : <u>467</u> feet from the <u>NORTH</u> line and <u>467</u> feet from the <u>WEST</u> line Section <u>30</u> Township <u>25-S</u> Range <u>38-E</u> NMPM LEA County <u>NEW MEXICO</u>		8. Well No. <u>23</u>
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 3085' DR		9. Pool name or Wildcat JUSTIS-BLINEBRY-TUBB-DRINKARD

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☒ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOBS ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting and proposed work). SEE RULE 1103. For Multiple Completions: Attach diagram of proposed completion or recompletion.

- 1 Pull equipment out of the hole.
- 2 Set CIBP @ 5090'.
- 3 Notify OCD, and run MIT to 500 psi for 30 minutes.
- 4 Load the hole with inhibited packer fluid.
- 5 Send chart of successful test to Roy Johnson, Henry Petroleum and TA well.
- 6 Roy will then fill out a subsequent C-103 form and a copy of the chart & send to the OCD.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Roy R. Johnson TITLE REGULATORY TECH. DATE 12/10/2002

Type or print name ROY R. JOHNSON

Telephone No. (915)694-3000

(This space for State use)

APPROVED BY _____ TITLE _____ DATE 12/10/2002

Conditions of approval, if any: