

UNITED STATES
DEPARTMENT OF THE INTERIOR

SUBMIT IN TRIPLICATE
(Other instructions
verse side)

Form approved.
Budget Bureau No. 42-R1424.

GEOLOGICAL SURVEY

SUNDY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen a well. Plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

5. LEASE DESIGNATION AND SERIAL NO.

LC 062060-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Byers Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Delaware Basin

11. SEC., T., R., M., OR BLK. AND

SURVEY OR AREA
Sed. 22-T26S-R35E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

1. OIL WELL ☐ GAS WELL ☐ OTHER Plug and Abandon

2. NAME OF OPERATOR
Sinclair Oil & Gas Company

3. ADDRESS OF OPERATOR
P. O. Box 1920, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
1980' fr the South and West lines.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well drilled to total depth 5500' Bell Canyon. No shows oil or gas.
8-5/8"OD surface casing set @ 322' and cemented w/200 sacks circulated to surface.
PROPOSE TO: Plug and Abandon as follows:

Fill hole w/mud laden material and Spot 30 sacks cement (100' plug across top of Delaware sand 5100-5200'). Spot 100' plug (30 sacks cement) above salt 950' to 1050'. Spot 30 sacks cement in bottom of surface casing 250' to 350'. Spot 20 sacks cement 0-50' in top of 8-5/8"OD surface and cellar, install regulation dry hole marker, clean and level location.

Above plug and abandon procedures approved by Mr. A. R. Brown, USGS, Hobbs, New Mex. by phone conversation to Mr. W. F. Burns, Sinclair Oil & Gas Company on 5-4-68.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Superintendent

DATE

5-6-68

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

Orig&4cc: USGS, Hobbs
cc: Regional Office
cc: file

*See Instructions on Reverse Side

MAY 7 1968

DISTRICT ENGINEER