

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions reverse side)Form approved.
Budget Record No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-0132237

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Hicks Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Undesignated

11. SEC., T., R., M., OR BLM. AND
SURVEY OR AREA

Sec. 15, T24S, R32E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER Dry Hole2. NAME OF OPERATOR
Tenneco Oil Company3. ADDRESS OF OPERATOR
P. O. Box 1031, Midland, Texas 797014. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface660' FSL & 1980' FWL of Sec. 15
T24S, R32E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3589.5 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

11-13-70) Perforated 4882-95'. Acidized w/250 gals. Swbd 1½ bbls. salt water

11-18-70) per hour. Sqzd. w/10 sx. Class "C" cmt.

12-21-70 to 1-25-71: Perforated 4856-66' & 4883-85'. Acidized w/250 gals and 1000 gals. acid. Fraced w/2500 gals. lease oil and 2000# sd. Pumped 16 bbls. saltwater per day, no oil.

Propose to plug and abandon as follows:

1. Spot cement over and 100 ft. above perforations. Use 15 - 20 sacks.
2. Pull all free 4½" casing.
3. Spot 25 sack cement plug in anhydrite (btm of plug @ 1150'). Leave mud between plugs.
4. Spot 100 ft. cement plug at shoe of surface casing (50' in and 50' out). Leave mud between plugs.
5. Spot 10 sacks cement at surface. Leave mud between plugs.
6. Install dry hole marker and clean location.

18. I hereby certify that the foregoing is true and correct

SIGNED

Johnny S. McDonald

TITLE

Engineer

FEB 1 1971

DATE Jan. 29, 1971

(This space for Federal or State office use)

APPROVED BY

TITLE

ARTHUR R. BROWN
DISTRICT ENGINEER

DATE

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED VERBAL APPROVAL FROM MR. ARTHUR BROWN 1-29-71.

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to land, air, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Notes: 12. There are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Presents to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such presents and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant third contents not soaked off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site was abandoned for final inspection looking to approval of the abandonment.

Page 10