

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division
1625 N. French Dr.
Hobbs, NM 88240

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reserv

Use "APPLICATION FOR PERMIT-" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

Oil Gas
☒ Well ☐ Well ☐ Other

2. Name of Operator

Primal Energy Corporation

3. Address and Telephone No.

211 Highland Cross #227, Houston, TX 77073 (281)821-5600

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit H.1980' FNL & 660' FEL, Sec. 12, T24S, R32E

5. Lease Designation and Serial No.

NM02889

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Wimberty #3

9. API Well No.

30-025-24468

10. Field and Pool, or Exploratory Area

Triple X Delaware

11. County or Parish, State

Lea, NM

12. **CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

TYPE OF SUBMISSION

- ☒ Notice of Intent **AMENDED**
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work.
If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

NOTE Prior to step 3, the casing will be tested. If OK, we will ask for Temporary Abandonment.

- POOH with all production equipment.
- Set cement plug with 45 sxs. from 4650' to 5029'. *Set Plug 50' In And 50' Out Of Top 5 1/2" Stub-Tag*
- Cut and pull 5 1/2" casing below salt at 1400'. *Set 60 sx. plug from 1382 to 1282'.*
- Set 50 sx. plug across surface casing shoe. Set 50' surface plug. Erect dry hole marker. Clean and restore location.

Tag

14. I hereby certify that the foregoing is true and correct

Signed

Title Manager, Operations & Engineering

Date January 4, 2000

(This space for Federal or State office use)

(ORIG. SGD.) **DAVID R. GLASS**

Approved by

Title

PETROLEUM ENGINEER

Date

JAN 11 2000

Conditions of Approval, if any:

SEE ATTACHED FOR

CONDITIONS OF APPROVAL

Title Manager, Operations & Engineering knowingly and willfully to make to any department or agency of the
United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

See Instructions On Reverse Side

GWW

2000 JAN -7 A 9 02

RECEIVED

RECEIVED