

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE\*  
(Other instructions on re-  
verse side)

Expires August 31, 1985  
5. LEASE DESIGNATION AND SERIAL NO.  
NM28062  
6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐  
2. NAME OF OPERATOR Herman J. Ledbetter  
3. ADDRESS OF OPERATOR P.O. Box 5879 Abilene, Texas 79608  
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface  
990 Feet From The South Line and 330 Feet From The East Line  
14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.)  
29800GR

7. UNIT AGREEMENT NAME  
8. FARM OR LEASE NAME  
W.J. Frost  
9. WELL NO.  
1  
10. FIELD AND POOL, OR WILDCAT  
South Leonard  
11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA  
Sec. 23-26S-37E  
12. COUNTY OR PARISH  
Lea  
13. STATE  
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐  
FRACTURE TREAT ☐  
SHOOT OR ACIDIZE ☐  
REPAIR WELL ☐  
(Other) ☐  
PULL OR ALTER CASING ☐  
MULTIPLE COMPLETE ☐  
ABANDON\* ☒  
CHANGE PLANE ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐  
FRACTURE TREATMENT ☐  
SHOOTING OR ACIDIZING ☐  
(Other) ☐  
REPAIRING WELL ☐  
ALTERING CASING ☐  
ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)

Propose to plug and abandon this well as follows:

1. Set a 25 sack plug just above perforation at 2660 - 2967.
2. Set a 25 sack plug just below the salt.
3. Cut and pull 4 1/2 casing. place 100' plug in & out of stub & tag plug.
4. Set a 25 sack plug in base of 8 5/8 surface casing.  
(Bottom of 8 5/8 casing at 1036 cemented with 375 sacks, circulated.)
5. Set marker at top of 8 5/8 casing. w/50' plug @ surface.

18. I hereby certify that the foregoing is true and correct.

SIGNED Herman J. Ledbetter TITLE Operator

DATE 9/22/93

(This space for Federal or State office use)

APPROVED BY (ORIG. SGD.) JOE G. LARA TITLE PETROLEUM ENGINEER

DATE 10/18/93

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side