

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.O.S.		
LAND OFFICE		
OPERATOR		

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease
State <input type="checkbox"/> Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
NM-60359

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Exxon Corporation	8. Farm or Lease Name East El Mar Federal
3. Address of Operator P.O. Box 1600, Midland, TX 79702	9. Well No. 1
4. Location of Well UNIT LETTER <u>O</u> <u>660</u> FEET FROM THE <u>South</u> <u>1980</u> FEET FROM <u>East</u> <u>27</u> LINE, SECTION <u>26S</u> TOWNSHIP <u>33E</u> RANGE <u>33E</u> NMPM.	10. Field and Pool, or Wildcat Wildcat-Delaware
15. Elevation (Show whether DF, RT, GR, etc.) 3300.2'-GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input checked="" type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

1. MIRU. POH w/rods. Install shoptested and POH w/tubing.
2. Rig up wireline. Make a guage ring run to top of perfs. Make a bit run only if necessary.
3. RIH with a CIBP and set at 5035' use wireline measurement if collar log is unavailable.
4. RIH and dump bail 35' of cement on CIBP, RD wireline.
5. RIH with tubing and circulate with inhibited water containing 10 gals. C-7672 and 20 gals. C-7720 per 100 bbls.
6. Pressure test casing to 500#.
7. RIH with rods and RDMO.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signed Jeanmarie Whitlock TITLE Office Assistant DATE 5/22/86

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE JUN 2 1986

CONDITIONS OF APPROVAL, IF ANY: