

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions
reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-061936

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

NONE

7. UNIT AGREEMENT NAME

Cotton Draw Unit

8. FARM OR LEASE NAME

Cotton Draw Unit

9. WELL NO.

60

10. FIELD AND POOL, OR WILDCAT

Paduca Delaware

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 10, T-25-S, R-32-E

12. COUNTY OR PARISH

Lea

13. STATE

N. M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to fill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

DEC 6 10 54 AM '66

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

T. Inc.

3. ADDRESS OF OPERATOR

Box 728 - Hobbs, Mexico

4. LOCATION OF WELL (Report location
See also space 17 below.)
At surface

and in accordance with any S. vents.*

Well located 2145' from the North Line, and 2310' from the
East Line of Section 10, T-25-S, R-32-E, Lea County, N. M.

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3463' (D. F.)

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☒
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☐
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐
☐

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to do the following work on subject well:

1. Tag bottom with tubing, if bottom below 4738', skip items 2 & 3.
2. Using pump truck, mud tank, tubing with saw-toothed pup-joint, & tongs to rotate, reverse circulate hole clean to 4870' with water.
3. Swab test well, if results unsuccessful, proceed to item 4.
4. Pull tubing and frac with 2500 gallons refined oil, 2500 pounds of sand, and flush with 100 bbls lease crude.
5. Swab well, recover load oil, Test, and place well on production.

18. I hereby certify that the foregoing is true and correct

SIGNED

Dan Gillett

TITLE

Assistant District

DATE Nov. 29, 1966

(This space for Federal or State office use)

Superintendent

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED

NOV 29 1966

A. H. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side