

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER: <u>Trn well</u>	7. Unit Agreement Name <u>NMFU</u>
2. Name of Operator <u>CONOCO INC.</u>	8. Farm or Lease Name <u>Langlie Jack Unit</u>
3. Address of Operator <u>P. O. Box 460, Hobbs, N.M. 88240</u>	9. Well No. <u>2</u>
4. Location of Well UNIT LETTER <u>P</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>17</u> TOWNSHIP <u>24S</u> RANGE <u>37E</u> N.M.P.M.	10. Field and Pool, or Wildcat <u>Langlie Math 7 Puns Que</u>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County <u>Lea</u>

## 16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input checked="" type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER _____		OTHER _____	

## 17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- ① MIRU wireline Services
- ② Set CIBP @ 3150'
- ③ Spot 7 sxs class "C" neat cmt on top of CIBP
- ④ Spot a 100' cmt plug from 2540'-2640' (plug = 13 sxs class "C" neat)
- ⑤ Set retainer @ 400' and pmp 250 sxs class "C" cmt below. circ. to surface (holes between 469' & 815')
- ⑥ Rig down
- ⑦ Verbal app'l for this procedure given by Eddie Seay on 11/25/85.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Karl Vogel TITLE Administrative Supervisor DATE 11-25-85

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT 1 SUPERVISOR

DEC - 2 1985

RECEIVED  
NOV 27 1985  
O.C.D.  
HOBBS OFFICE