

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103

Supersedes Old

C-102 and C-103
Effective 1-1-65

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		<p>5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/></p>
<p>1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/></p>		<p>5. State Oil & Gas Lease No. -----</p>
<p>2. Name of Operator Skelly Oil Company</p>		<p>7. Unit Agreement Name -----</p>
<p>3. Address of Operator P. O. Box 1351, Midland, Texas 79701</p>		<p>8. Farm or Lease Name J. W. Sherrell</p>
<p>4. Location of Well UNIT LETTER N 990 FEET FROM THE South LINE AND 2172 FEET FROM THE East LINE, SECTION 31 TOWNSHIP 24S RANGE 37E NMPM.</p>		<p>9. Well No. 5</p>
<p>15. Elevation (Show whether DF, RT, GR, etc.) 3244' DF</p>		<p>10. Field and Pool, or Wildcat Jalmat (Yates)</p>
		<p>12. County Lea</p>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to low volume of gas production, this well has become uneconomical to operate. We propose to plug and abandon the well as follows:

- 1) Move in pulling unit. Pull production equipment.
- 2) Spot cement plug in open hole and 7" OD casing 2600-3000'.
- 3) Spot cement plug in 7" OD casing 900-1400'.
- 4) Spot 10 sack cement plug at surface.
- 5) Set marker.

All intervals not cemented will be filled with 10# mud.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

(Signed) J. R. Avent

J. R. Avent

TITLE **Dist. Admin. Coordinator**

DATE **Feb. 27, 1973**

APPROVED BY 
CONDITIONS OF APPROVAL, IF ANY:

TITLE **SUPERVISOR DISTRICT I**

DATE **1973**