

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator BURLESON and HUFF		8. Farm or Lease Name Woolworth	
3. Address of Operator P. O. Box 935 - Midland, Texas 79701		9. Well No. 1	
4. Location of Well UNIT LETTER K 2310 FEET FROM THE West LINE AND 1650 FEET FROM THE South LINE, SECTION 33 TOWNSHIP 24S RANGE 37E NMPM.		10. Field and Pool, or Wildcat Jalmat	
15. Elevation (Show whether DF, RT, GR, etc.) 3247' DF		12. County Lea	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has collapsed pipe in the top of the Yates @ 2600'. Plan to abandon using following procedure:

1. Set 100' plug @ top of Yates, base of salt @ 2500'; *in fault stub,*
2. Cut and pull 1000' of 5 1/2" and spot 100' cement plug @ top of salt @ 950';
3. Set 100' plug @ base of surface pipe @ 400';
4. 10' plug in top with marker;
5. Place mud between plugs.

You will be notified in sufficient time to witness this operation.

When land is put back to original contour we will file so that final inspection can be given this location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *John J. Brown* TITLE **Partner** DATE **June 27, 1975**

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: