

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPI
(Other instructions
verse side)

FE-
re-

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC-057509

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
G. L. Erwin "B" NCT-2

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Justis Paddock

11. SEC. T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 35, T-24-S, R-37-E

12. COUNTY OR PARISH

Lea

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Texaco Inc.

3. ADDRESS OF OPERATOR

P.O. Box 730, Hobbs, NM 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

660' FSL & 660' FEL, Unit Letter P
API #3002511362

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3172' KB

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 1) MIRU. Kill well w/10# wtr. TOH w/rods & pmp. NU BOP. Pull tbq.
- 2) TIH w/4.75" bit & 7" csg scraper on WS. C/O hle to TD.
- 3) POH. TIH w/trtg pkr & WS. PSA 4850'.
- 4) A/perfs w/3000 gals 15% NEFE in 3 stgs using RS.
- 5) Fl w/30 BFW. SI for 1 hr.
- 6) Sqz perfs w/2 drums scale inhibitor & flush w/150 BSW.
- 7) SI well for 48 hrs. Swab back load to kick off well.
- 8) Rerun prod equip & put well on test.

RECEIVED
JAN 8 11 11 AM '90
BUREAU OF LAND MGMT.
HOBBS, NM.

18. I hereby certify that the foregoing is true and correct

SIGNED

M. C. Duncan

TITLE

M. C. Duncan

Engineer's Assistant

DATE

01/07/91

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side