District Office	State of New Mexico Ene., Minerals and Natural Resources Department OIL CONSERVATION DIVISION P.O. Box 2088		ſ	Form C-103 Revised 1-1-89
<u>DISTRICT I</u> P.O. Box 1980, Hobbs, NM 88240			WELL API NO.	
DISTRICT II Santa Fe, New Mexico 87504-2088 P.O. Drawer DD, Artesia, NM 88210			5. Indicate Type of Lease STATE FEE X	
DISTRICT III 1000 Rio Brazos Rd., Aziec, NM 87410			6. State Oil & Ga	
( DO NOT USE THIS FORM FOR PF DIFFERENT RESE (FORM	TICES AND REPORTS ON W ROPOSALS TO DRILL OR TO DEEP ERVOIR. USE "APPLICATION FOR F C-101) FOR SUCH PROPOSALS.)	EN OR PLUG BACK TO A	7. Lease Name of	Unit Agreement Name
1. Type of Weil: OIL OAS WELL VELL	omer Water	r Injection Well	Humphrey (	ueen Unit
2. Name of Operator Bridge Oil Company, L.P.			8. Well No. 9	
3. Address of Operator	Drive, Suite 400, Dalla	as, Texas 75251	9. Pool name or V Langlie Ma	<b>Vident</b> attix 7 Rivers Queen
4. Well Location Unit Letter F . 17	50 Feet From The North	Line and 23	10 Feet From	a The West Line
7	250	775		
Section 3	10. Elevation (Show wheth	her DF, RKB, RT, GR, etc.)	NMPM	
//////////////////////////////////////	Appropriate Box to Indicat		eport or Othe	
	TENTION TO:		SEQUENT F	
	CHANGE PLANS		G OPNS.	
PULL OR ALTER CASING CASING TEST AND C				
OTHER: Deepen well pa	ast plug back X			
12. Describe Proposed or Completed Ope work) SEE RULE 1103.	erntions (Clearly state all pertinent details	, and give pertinent dates, inclu	iding estimated date of	f starting any proposed
	Turners and seat turking	ng and casing. D	rill out hy	dmomito con @ 34EE1
set packer. Pressur injection. After 7	Thispect and test tubin 500'. Acidize with 200 re test casing to 500 p days injection, run in this work was obtained	00 gallons 15% NE psi and monitor f njection profile	FE. Run 2- For 30 minut and tempera	7/8" tubing and es. Return well to ture survey.
Clean out fill to 35 set packer. Pressur injection. After 7 Verbal approval for Iberby certify that the information above by	500'. Acidize with 200 re test casing to 500 j days injection, run in	00 gallons 15% NE psi and monitor f njection profile d from Evelyn Dow	FE. Run 2- For 30 minut and tempera ms on Decem	7/8" tubing and es. Return well to ture survey.
Clean out fill to 35 set packer. Pressur injection. After 7 Verbal approval for Ihereby certify that the information shows in	500'. Acidize with 200 re test casing to 500 g days injection, run in this work was obtained	00 gallons 15% NE psi and monitor f njection profile d from Evelyn Dow and baief. Regulatory	FE. Run 2- For 30 minut and tempera ms on Decem	7/8" tubing and es. Return well to ture survey. ber 14, 1990.
Clean out fill to 35 set packer. Pressur injection. After 7 Verbal approval for Ihereby certify that the information above in SKONATURE	500'. Acidize with 200 re test casing to 500 g days injection, run in this work was obtained	00 gallons 15% NE psi and monitor f njection profile d from Evelyn Dow and baief. Regulatory	FE. Run 2- For 30 minut and tempera ms on Decem	7/8" tubing and es. Return well to ture survey. ber 14, 1990.