

Submit 3 Copies
to Appropriate
District Office

STATE OF NEW MEXICO
Encl. Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	WELL API NO.
2. Name of Operator Bridge Oil Company, L.P.	5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
3. Address of Operator 12404 Park Central Dr., Ste. 400, Dallas, TX 75251	6. State Oil & Gas Lease No.
4. Well Location Unit Letter <u>E</u> : <u>1980</u> Feet From The <u>North</u> Line and <u>330</u> Feet From The <u>West</u> Line Section <u>14</u> Township <u>25S</u> Range <u>37E</u> NMPM LEA County	7. Lease Name or Unit Agreement Name Langlie Mattix Queen Unit
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	8. Well No. 18
	9. Pool name or Wildcat Langlie Mattix 7 Rivers Queen

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐


12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Set CIBP + 35' cement @ 3200'. Spot 100' cement plug from 2500'-2400'. Cut and pull approximately 1070' of 5-1/2" production casing. Set 150' cement plug from 1000'-1150'. Tag plug. Perforate @ 250' and squeeze 100' cement plug from 150'-250'. Place 10sx cement plug in top of casing. Cut off casing 3' below ground surface and weld on steel plate. Set dry hole marker. Fill pits, level location and clear all junk.

NOTE: Hole to be filled with 10# brine + 25# gel/bbl.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE



TITLE

Manager, Regulatory
& Production Analysis

DATE 11-12-91

(214) 788-3363
TELEPHONE NO.

TYPE OR PRINT NAME

J. Michael Warren

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON

DISTRICT I SUPERVISOR

APPROVED BY

TITLE


DATE

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

NOV 15 1991

DIL. DRAMMATIC WELL SITE
LANGUE MATTIX QUEEN UNIT WELL NO. 13
LANGUE MATTIX (QUEEN) FIELD
LEA COUNTY, NEW MEXICO



RECEIVED

NOV 14 1991

C/20
HOBBS OFFICE