

Form 9-331  
(May 1963)UNIT STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICA  
(Other instructions on  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-032650 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

A. B. Coates "C"

9. WELL NO.

6

10. FIELD AND POOL, OR WILDCAT

Justis Ellenburger

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA25  
Sec. 24, T24S, R37E

12. COUNTY OR PARISH 13. STATE

Lea

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS  
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)1. OIL ☒ WELL GAS ☐ WELL OTHER ☐

2. NAME OF OPERATOR

Tidewater Oil Company

3. ADDRESS OF OPERATOR

Box 249, Hobbs, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface

660' FNL &amp; 1980' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3083 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☒

(Other)

PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☐CHANGE PLANS ☐

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☐(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Well presently completed in the Ellenburger zone thru perf. 8015-38.  
Water has increased and well will not flow. It is proposed to set  
cement retainer at 7990' and squeeze with 100 sx. cement. Perforate  
with two shots per foot 7958-68'. Run 2" tubing with Sweet packer.  
Acidize with 500 gals. mud acid and swab well in.

18. I hereby certify that the foregoing is true and correct

SIGNED

O. E. Wade

TITLE

Area Supt.

DATE

1-18-65

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side

