

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE
(Other instructions
reverse side)

Direct approval
Budget Bureau No. 42 R1424
5. LEASE DESIGNATION AND SERIAL NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐ SHUT IN GAS WELL		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR GETTY OIL COMPANY		8. FARM OR LEASE NAME A. B. COATES "D"	
3. ADDRESS OF OPERATOR P. O. BOX 249, MORRIS, NEW MEXICO 88240		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660' FSL, and 1,980' FWL, Section 24		10. FIELD AND POOL, OR WILDCAT LANGLIE MATTIX	
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 24-T-25-S, R-37-E	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3068' (Tubing Head)		12. COUNTY OR PARISH DEA	
		13. STATE N. MEX.	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐	WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐	FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒	SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
REPAIR WELL ☐	CHANGE PLANS ☐	(Other) ☐	(Other) ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The well is depleted in the Langlie Mattix Zone and no other zones are considered productive. We propose to plug and abandon as follows:

1. Rig up pulling unit.
2. Load well with lease brine. Pull 2-3/8" tubing. Remove bull plug and perforated nipple.
3. Go in hole with 2-3/8" tubing and Baker Abandonment Bridge Plug. Set Bridge Plug @ 2,940'.
4. Circulate lease brine out and load well with mud. **AMENDMENT: Increase cement plug from 25 sacks to 50 sacks at 2940 feet to 2960 feet.**
5. Set a 25' cement plug from 2,940' to 2,915'.
6. Pull tubing. Set a 50' cement plug at surface.
7. Erect surface marker with proper identification.

18. I hereby certify that the foregoing is true and correct

SIGNED G. L. Wade

TITLE AREA SUPERINTENDENT

DATE 2-10-72

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.